


TOSHIBA

FILE NO. 330-200729GR
Rev.02

SERVICE MANUAL

DLP PROJECTOR

TDP-P9, TDP-PX10



The above models are classified as green product (s) (*1), as indicated by the underlined serial number (s).

This Service Manual describes replacement parts for green product (s). When repairing any green product (s), use the parts described in this manual and lead-free solder (*2).

For (*1) and (*2), see the next page.

(*1)

GREEN PRODUCT PROCUREMENT

The EC is actively promoting the WEEE & RoHS Directives that define standards for recycling and reuse of Waste Electrical and Electronic Equipment and for the Restriction of the use of certain Hazardous Substances. From July 1, 2006, the RoHS Directive will prohibit any marketing of new products containing the restricted substances.

Increasing attention is given to issues related to the global environmental. Toshiba Corporation recognizes environmental protection as a key management tasks, and is doing its utmost to enhance and improve the quality and scope of its environmental activities. In line with this, Toshiba proactively promotes Green Procurement, and seeks to purchase and use products, parts and materials that have low environmental impacts.

Green procurement of parts is not only confined to manufacture. The same green parts used in manufacture must also be used as replacement parts.

(*2)

LEAD-FREE SOLDER

This product is manufactured using lead-free solder as a part of a movement within the consumer products industry at large to be environmentally responsible. Lead-free solder must be used in the servicing and repair of this product.

WARNING

This product is manufactured using lead free solder.

DO NOT USE LEAD BASED SOLDER TO REPAIR THIS PRODUCT !

The melting temperature of lead-free solder is higher than that of leaded solder by 86°F to 104°F (30°C to 40°C). Use of a soldering iron designed for lead-based solders to repair product made with lead-free solder may result in damage to the component and or PCB being soldered. Great care should be made to ensure high-quality soldering when servicing this product — especially when soldering large components, through-hole pins, and on PCBs — as the level of heat required to melt lead-free solder is high.

Conventions

The following conventions are used in this manual

Screen Messages	Denote actual messages that appear on screen.
Note	Give bits and pieces of additional information related to the current topic.
Warning	Alert you any damage that might result form doing or not doing specific actions.
Caution	Give precautionary measures to avoid possible hardware or software problems.
Important	Remind you doing specific actions relevant to the accomplishment of procedures.

Table of Contents

1	System Introduction	1
1.1	Technical Specification.....	1
1.2	Lamp Specification	2
1.3	TDP-P9 System Block Diagram.....	4
2	Firmware Upgraded Flow	5
2.1	Setup Tool/Equipment	5
2.2	Upgrading Procedure	5
3	Machine Disassembly and Replacement	10
3.1	Tools	10
3.2	Disassembly Procedure	11
3.3	Disassembly Lamp Module	17
3.4	Disassembly the speaker and keypad	18
4	Troubleshooting and Verifying the Repair	19
4.1	Troubleshooting	19
4.2	Verifying the Repair	25
5	Connector Information	31
5.1	Main Board	31
5.2	Ballast Board.....	32
5.3	Power board	32
6	FRU (Field Replaceable Unit) List	33
6.1	Mechanical Drawing	34
6.2	Other drawing	36
6.3	Drawing of Optical Engine	38
6.4	Spare Parts List	40
	Appendix A : Main board function diagram	41

1 System Introduction

1.1 Technical Specification

	TDP-P9
Display Type	0.55" DMD/ 12 ° / LVDS-Type X
Resolution(Pixels)	XGA (1024 x 768)
Lens	Manual Zoom (1.17X) F=2.5~2.74 f=22~25.5mm Screen Size 34 – 307 inches
Contrast Ratio	2000:1
Uniformity	> 54%
Lamp	Osram E19, 200W
Projection Type	Front, Rear,
Input Source	D-Sub 15 pin, S-Video, Composite Video, YPbPr, Audio in(Stereo phone jack), USB,
Video Compatibility	NTSC 4.43, NTSC-M PAL-60, PAL-M, N, (B, D, G, H, I) SECAM
Scanning Frequency Horizontal Frequency Vertical Frequency	15 -80 KHz 50 – 85 Hz
Digital Keystone Correction	Vertical + / - 16 °
Integrated Speaker	1 x 2W
Noise Level	Less than 35 dBA in Normal mode, or 32 dBA in lamp saver mode
Environment	Operating: Temperature:+5 °C ~ +35 °C (41oF–95oF) Humidity:10% ~ 90% Storage: Temperature:-20 °C to 60 °C Humidity:90% maximum (No condensation)
Power Requirement	AC 90 -264V, 50/60 Hz
Power Consumption	260W Standby mode: less than 10W
Dimension	210 x 65 x 165 mm(without elevator foot)
Weight	< 3 lb

Note: Designs and specifications are subject to change without prior notice

Lamp Specification

Product Type: Short arc mercury lamp with reflector.

The product is a lamp system consisting of a short arc burner within a reflector and an electronic lamp driver.

Type lamp	P-VIP 150-200/1.0 E19 Identcode: 489 43B
Type driver	PT VIP 200AC/100-240 H1 Identcode: 516914

Initial Characteristics

Lamp power : 200 W
Measurement : Integrating sphere
Aperture: 6.0 mm round

Power consumption

UV-output	UVA	315-380 nm	4 W typical
	UVB	280-315 nm	< 0.1 W typical
	UVC	248-280 nm	< 0.01 W typical
Total visible flux		380-780 nm	42 W typical
IR		780-1650 nm	< 1 W typical

Note: More information about lamp replacement procedure, resetting lamp timer and lamp part number, please check the page 17.


Attention for handling

- ◆ Do not touch the lamp until it has cooled completely, because the lamp is very hot during operation and immediately after turned off.
- ◆ The lamp has to be fixed firmly to the base or socket.
- ◆ Turn off the power supply during maintenance.
- ◆ Do not hold the lamp except outer surface of the reflector.
- ◆ Wear protective gloves and eyeglasses when handling the lamp.
- ◆ Any unusual shock or vibration to the lamp should be avoided.
- ◆ The lamp contains the mercury. Its breakage might cause mercury to flow out of the reflector. Please manage provision at the customer's product.
- ◆ Do not pull the lead wire and plug by more than 24.5N.
- ◆ Please be careful of handling the lamp because it is made of glass.
- ◆ Please notice for keeping or handling the lamp, because there is a projection of this lamp with reflector ahead.
- ◆ Do not touch the bulb and the mirror area of the reflector.

Attention for use

- ◆ Do not close or cover the lamp with any flammable stuff.
- ◆ During operation, the lamp is under extremely high pressure. Please manage provision at the customer's product to prevent fragments of bulb and mercury from flowing out of it. If the lamp bursts in case of an emergency, the sound will be occurred.
- ◆ Lamp operation should be with the specified lamp driver and the system ONLY.
- ◆ Do not look at the lamp directly during operations.
- ◆ Do not expose your skin directly. We recommend to you to put on something for protection for your skin. For example, long sleeve shirt, gloves, glasses and so on.
- ◆ Do not modify the lamp and never use a lamp that has been modified.
- ◆ Any unusual shock or vibration to the lamp should be avoided during operation.
- ◆ Do not use any broken lamps.
- ◆ Dispose of used lamps according to your local instruction.
- ◆ Do not turn on the lamp while the system is opened.
- ◆ The lamp contains mercury. If the lamp bursts during operation ventilate the area sufficiently to avoid inhaling harmful mercury fumes.
- ◆ Use the lead below 200 °C to prevent a deterioration of cladding clad of the fluorocarbon resin.
- ◆ The lead wire insulation clad shouldn't touch the reflector.
- ◆ Exchange the lamp that has already passed the life time immediately.

1.2 TDP-P9 System Block Diagram



2 Firmware Upgraded Flow

This chapter provides the information regarding relevant equipments and upgrading procedure for firmware upgrade.

Note:

Please check the firmware and composer version before any firmware upgrade procedures. During firmware download period, please do not shut down PC or projector, this will cause flash memory's damage. And need to return the unit to manufacturer for flash memory recovery.

2.1 Setup Tool/Equipment


- Computer
- USB Cable (See the picture)
- Power Cord




2.2 Upgrading Procedure

Installing [DLP Composer (TM) Lite]

1. Double-click [DLP Composer Lite vX.X Setup.exe].
2. Installation starts. Click [Next] to continue the installation process.
3. On the [License Agreement] screen, move the scroll bar on the right to the bottom, select [I accept and agree to be bound by all the terms and conditions of this License Agreement], and click Next to continue the installation process.
4. On the Select [Installation Type] screen, select [ALL] and click [Next] to continue the installation process.




5. When the installation is finished, click [Finish] and reboot the PC. (A shortcut to DLP Composer (TM) Lite is created on the desktop.)




And copy the file “FlashDeviceParameters.txt” into the C:\ Program Files\ DLP Composer Lite X.X

USB Support - Installation (All Platforms)

This release includes support for a USB communications interface to DDP2230-based projectors. The setup program includes the files needed to install USB support (for Windows 98/Me/2000/XP only -- Win95, WinNT and Windows Vista are not supported). After DLP Composer™ Lite is installed, to install the USB support, choose the "Install DLP Processor USB Driver" icon under "DLP Composer™ Lite" in your Start menu.



Follow the instruction on the screen to press any key and wait for the installation done.




Operating procedure

1. Connect the Projector and PC via USB cable.
2. Double-click [**DLP Composer (TM) Lite**]. The following screen will appear.



3. Select [**Edit**]/[**Preferences**]/[**Communications**] to check **USB** in [**Projector Interface**].








12. Wait for the Completion of Burning and then remove Power Cord and Burning Cord

Note: In case, the device manager can't recognize the DDP2230 as blow, please disable this device. This will not affect upgrade procedure.

3 Machine Disassembly and Replacement



3.1 Tools



Item	Photo
Long Nose Nipper	
Hex Sleeves 5mm	
Screw Bit(+):107 Screw Bit(+):101 Screw Bit(+):102	
Anti-static wrist strap	
Anti-static wrist gloves	



3.2 Disassembly Procedure

Warning



- ◆ Put on the Static Electricity Ring when starting for repair.
- ◆ Repair Environment suggest in Clean-room class 10000. Do not remove Optical Engine or DMD panel outside the clean room. Please return the optical engine to supplier if your repair condition can not meet the requirement.
- ◆ While screwing or unscrewing screws, please keep the screwdriver straight. Keeping screwdriver inclined will damage the screw holes.
- ◆ Please turn off the power before replacing any parts.
- ◆ Please wait for the projector lamp cooling down and turn off the power before changing it. Never touch or hit the lamp module when replacing the lamp.
- ◆ When you replace the projector lamp, never touch the new lamp with your bare hands. The invisible residue left by the oil on your hands may shorten the lamp life. Use lint-free gloves or finger cots are recommended.



Step	Figure	Description
1	 <p>The diagram shows a top-down view of the projector. A strap is shown being attached to a small tab on the top surface. A circular lens cover is shown detached from the front lens, with a line pointing to it from the label 'Lens Cover'.</p>	<p>Press the power button to shutdown the projector and disconnect the power cord.</p> <p>If the lamp is hot, please do not start any procedure until the projector lamp cools down.</p> <p>Flip the projector and remove the lens cover.</p>
2	 <p>The diagram shows a top-down view of the projector. Three screws are indicated by red dashed lines and the label 'Screw'. The screws are located at the front-left, front-right, and back-right corners of the top surface.</p>	<p>Flip the projector on the table.</p> <p>Loosen the screws as shown.</p>

Step	Figure	Description
3	 <p>The diagram illustrates the process of removing the top cover and the flex flat cable (FFC) from the projector. The top cover is shown being lifted away from the main chassis. The FFC is shown being disconnected from the keypad area. Arrows indicate the direction of removal.</p>	<p>Turn the projector over and remove the top cover (Be careful of the FPCB between keypad and main board). Then disconnect the flex wire (FFC).</p> <p>Remove the screws on the back cover as shown.</p> <p>Note: Screw-mylar can cover on the screws to decorate the back cover.</p>
	 <p>The photograph shows the internal main board of the projector with several components highlighted by red circles and labeled with red arrows. The labels are: Front IR, O/E Fan, DC power in, Right Fan, Left Fan, Color wheel, CW sensor, and 5 pin for Ballast.</p>	<p>There is a photo showing you what the connector should be.</p>



Step	Figure	Description
4		<p>Remove all the screws on the IO panel and main board. Then you can get the main board off.</p> <p>Note: the leftest screws are different.</p>
5		<p>Spire off the lens ring and remove the screws on optical engine body, take off the engine and front cover. Then take the fans out.</p>

Screw


Step	Figure	Description
6		<p>Loosen the screws of the DC-DC module and take it out.</p>
7		<p>Remove the screws as shown and be careful to disconnect two wires under the ballast. Take the ballast off.</p>

Step	Figure	Description
8	 <p>Mylar</p> <p>Fan Holder *2</p>	Remove the mylar and you age the bottom cover assembly.
9	 <p>Fast Foot Cover</p> <p>Spring B</p> <p>Fast Foot Tooth</p> <p>Push Button Paint</p> <p>Spring A Leaver</p> <p>Front Foot Stand</p> <p>Front Foot Rubber</p>	Remove other assembly parts as photo showing.

3.3 Disassembly Lamp Module

Step	Figure	Description
1	 <p>Lamp Cover</p>	<ul style="list-style-type: none"> ● Turn off the projector. ● Unplug the power cord. ● Remove the lamp cover.
2		<ul style="list-style-type: none"> ● Loosen the two screws of lamp module ● Pull the lamp module out by lamp handle. ● Insert the new lamp module into the projector and tighten the screws. ● Replace the lamp cover and tighten the screws. <p>Note: Turn on the projector. If the lamp does not turn on after the warm-up period, please reinstall the lamp.</p>

3.4 Disassembly the speaker and keypad

Step	Figure	Description
1	 <p>The diagram shows an exploded view of the top cover assembly. At the bottom is the 'Top Cover' with various mounting points. Above it is the 'KeyPad B4' which is secured by four screws labeled 'S7'. A speaker wire labeled 'W5' is connected to the keypad. Below the keypad is the 'SPEAKER M1', which is also secured by two screws labeled 'S7'. Dashed lines indicate the alignment and removal path for these components.</p>	<p>Disassembly the speaker</p> <ul style="list-style-type: none"> ● Disconnect the speaker wire with keypad ● Remove the screws S7 x 2 ● Take the speaker M1 off. <p>Disassembly the keypad</p> <ul style="list-style-type: none"> ● Disconnect the speaker wire and W5 ● Remove the screws as shown ● Take the keypad B4 off.

4 Troubleshooting and Verifying the Repair

This chapter provides technicians with electronic background how to maintain the product. Moreover, you can get the appropriate operation to solve some complicated problems of component repairing and professional problems.




4.1 Troubleshooting

Warning

- Do not directly look into the lens to avoid eyesight damages.
- The projector is equipped with ventilation holes (intake) and ventilation holes (exhaust). Do not block or place anything near these slots, or internal heat build-up may occur, causing picture degradation or damage to the projector.

Confirm Software and hardware

- (1) Confirm FW version and lamp using hours(version and lamp hours in the help menu)
- (2) Confirm LED indicator

State/ Problems	Icon/ Messages	Close Messages	LED Indicators	
			TEMP	LAMP
Environment overheat			On	
Fan lock				
System error			F2	F2
Lamp life time	The lamp life is ending.	Press any key		
Lamp error				On


F2: Flash 2Hz

Flash 2Hz : Flash red light for each 0.5 sec.


- (3) Confirm cable connection well.
- (4) Confirm Main-board version

Note: Swapping modules that may be defective with others known to be good is generally an ideal way to find the module responsible for the problem. A failure symptom is rarely caused by more than one module, so you will not usually need to replace more than one to correct a particular failure. Whatever main board, ballast, IR board, power board, lamp module or optical engine are all suitable to check by swapping modules.

Power Source Troubleshooting:





How to check the power board?





- check the 380v output on connector 1(see ballast board page 33)
- check the fuse on the power board



Light and Sound Troubleshooting





Video Signal Troubleshooting



Abnormal Image Troubleshooting



Operation Function Troubleshooting



4.2 Verifying the Repair

After repairing projector (Disassembling and assembling projector), Repair center should verify the quality of repaired unit.

(1) Signal test (Each I/O can function normally)

Connect all connector to the jacks one after the other to check whether each channel can project normally

I/O port	Monitor In (VGA)
Test Equipment	Standard Pattern generator (Ex. Quantum data)
Signal format	1024*768 60Hz

I/O port	Video
Test Equipment	Standard Pattern generator (Ex. Quantum data) or DVD player
Signal format	NTSC

I/O port	S-Video
Test Equipment	Standard Pattern generator or DVD player
Signal format	480i

I/O port	USB
Test Equipment	PC and Remote controller
Test method	<ol style="list-style-type: none">1. Connect PC (laptop) VGA output to projector. Set PC (laptop) output signal to projector2. Connect projector USB to PC. Press remote controller page up/down to scroll presentation file up and down (ex Microsoft office series)

I/O port	Audio input
Test Equipment	Connect audio input to audio output of DVD player
Signal format	480i

(2) Operation test

Buttons operation

Button description	Test criteria
Power button	1. Mechanical motion (Up & Down) should be free from getting stuck when pressing the button 2. Press “power” button and projector will switch on
Menu/Enter	1. Mechanical motion (Up & Down) should be free from getting stuck when pressing the button. 2. Press Menu/Enter button can make projector function normally.
4-way button (Keystone/Auto/Source)	1. Mechanical motion (Up & Down) should be free from getting stuck when pressing the 4-way button. 2. Press Menu/Enter button can make projector function normally.

Foot adjuster operation

Foot adjuster.	Test criteria
Foot adjuster button	Foot adjusters should stretch downward smoothly by pressing the foot adjuster buttons on the two sides

Zoom ring and Focus ring

Ring	Test criteria
Zoom ring	Mechanical motion of rotating Zoom ring to the end of right and left by hand should be free from getting stuck.
Focus ring	The feeling of rotating Focus ring to the end of right and left by hand should free from seizing



(3) Image Quality



Projected image size: 60 inches (diagonal length)

Zoom ring: Adjust zoom ring to wide (Maximum projection size)

VGA

I/O port	Monitor In (VGA)
Test Equipment	Standard Pattern generator (Ex. Quantum data)
Signal format	1024*768 60Hz
Projected image size	60" in diagonal length

Test Pattern	Test criteria
	Full white Apparent color strip, bend and streak corner on the projected image are not allowable
	256 level RGB --256 level of RGB color should be distinguishable, at least Red color scales should be. -- For each RGB 256 levels, Noise or color deviation in R, G, and B single level respectively are acceptable.
	16 gray level --16 level of gray level color should be distinguishable --When Gamma selected to "RGB" Not distinguishable of 2 brightest levels /2 darkest levels are acceptable.

	Gray 10 Blemish, stain are not allowable on the projected screen
	Full darkness Light leak in the non-effective area. Should be less than 0.7 lux(<0.7lux)

S-Video

I/O port	S-Video
Test Equipment	Standard Pattern generator (Ex. Quantum data)&DVD player
Signal format	480i
Criteria	No apparent color deviation on the projected image

Video

I/O port	Video
Test Equipment	Standard Pattern generator (Ex. Quantum data)&DVD player
Criteria	No apparent color deviation on the projected image

(4) Resolution

I/O port	VGA
Test Equipment	PC
Test Method	<ol style="list-style-type: none"> 1. Rotate Zoom ring to wide mode (Maximum projected image) 2. Fix projector to set diagonal length of projected image to 60". 3. Adjust focus ring to make resolution of 4 corners and center are balanced. 4. Check the characters should be recognized easily. 5. Rotate Zoom ring to tele mode (Minimum projected image) 6. Adjust focus ring to make resolution of 4 corners and center are balanced. 7. Check the characters should be recognized easily.


(5) Front and Rear infrared sensor

Device	Front and Rear infrared
Test Equipment	Remote controller
Test method	<ol style="list-style-type: none"> 1. Cover front sensor and operate remote controller to test rear sensor 2. Cover rear sensor and operate remote controller to test front sensor

(6) Brightness measurements

Test items	Brightness measurements
Test Equipment	Chroma automatic system (The alternative is CL-200)
Test method	Measure 9 points
Criteria	Marketing spec 20% off

(7) Safety test equipments

Test items	Safety test
Test Equipment	Safety analyzer
Test method	<ol style="list-style-type: none"> 1. Clamp the metal shell of VGA connector 2. Plug the power cord to socket 
Test criteria	<p>GND 30A 3sec 100mΩ</p> <p>DCW 2506V 1sec 250uA</p> <p>Single Step OFF</p>


(8) Cosmetic standard for repaired projector

Follow cosmetic standard of repair center.

5 Connector Information


This section provides each connector location on boards and function of each board. They will be useful for your detecting the defective boards.

5.1 Main Board




Connector	Description
No 1	Left FAN
No 2	Front IR
No 3	O/E FAN
No 4	Power supply
No 5	Color Wheel control
No 6	Color Wheel Sensor
No 7	Keypad control
No 8	Right FAN
No 9	Ballast control

5.2 Ballast Board



Connector	Description
No 1	Lamp power supply
No 2	Connect to DC-DC board
No 3	AC Power Input

5.3 DC-DC Power board



Connector	Description
No 1	Connect to main board
No 2	Thermal feedback
No 3	Safety switch
No 4	DC power in


6 FRU (Field Replaceable Unit) List


Introduction

This section is a list of all the FRU removal. Following the FRU table of contents is an enlarged view of the entire projector, which shows the primary FRUs in the projector.


When working on the projector, use appropriate anti-static precautions such as anti-static mats, wrist straps and grounded work surfaces. Failure to do this can destroy static-sensitive components and make the product inoperable.





6.1 Mechanical Drawing










6.2 Other drawing





6.3 Drawings of Optical Engine





6.4 Spare parts list (TDP-P9, TDP-PX10)


GREEN

No	Location	Description	Part No	
			P9	PX10
1	-	SCREW, M2*4*A1.3 B	75010614	
2	-	SCREW, M2.5*4*E0.7 NI	75010615	
3	-	SCREW, M2.5*6*A1.7 NI	75010616	
4	-	SCREW, M3*6*A2 NI	75010619	
5	-	SCREW, M3*26*D2 NI	75010621	
6	-	SCREW, M3*23*E1.2 BL	75010622	
7	A1	CASE, SOFT	75010656	
8	A2	CARTON	75010658	
9	A3	PAD, CARTON	75010660	
10	A4	LABEL, LAMP	75010653	
11	A5	LABEL, LENS	75010654	
12	A6	LABEL, LAMP BURSTING	----	75010682
13	A7	PAD	75010659	
14	A8	LABEL, RATING	----	75010681
15	A9	LABEL, WARNING	75010652	
16	A10	MANUAL, QUICK GUIDE, P9, VER2	75011045	
17	A11	LABEL, HOT WARNING	75010655	
18	A12	STRAP, LENS CAP	75010677	
19	A13	CABLE, RGB	75010629	
20	A14	CORD, POWER, US	75010627	
21	A15	CORD, POWER, EU	75010626	----
22	A17	CORD, POWER, UK	75010628	----
23	A19	USERS MANUAL, CD-ROM, P9, VER2	75011046	----
24	A20	USER'S MANUAL, CD-ROM, PX10, VER2	----	75011147
25	A21	CORD, POWER, CHINA	75011044	----
26	B1	PC BOARD ASSY, MAIN, P9	75010670	
27	B2	PC BOARD ASSY, BALLAST	75010680	
28	B3	PC BOARD ASSY, MAIN POWER	75010671	
29	B4	KEYPAD	75010664	
30	B5	PC BOARD ASSY, IR	75010665	
31	B6	PC BOARD ASSY, PHOTO SENSOR	75010679	
32	B7	PC BOARD ASSY, DMD	75010666	
33	C1	COVER, TOP, P9	75010667	
34	C2	COVER, FRONT, P9	75010669	----
35	C2	COVER, FRONT, PX10	----	75010684
36	C3	COVER, BOTTOM	75010668	
37	C4	COVER, LAMP	75010641	
38	C5	COVER, LENS	75010645	
39	C7	PLATE, DECORATION CIRCLE	75010639	
40	C8	COVER, IR, FRONT	75010642	
41	C9	FOOT ASSY, FRONT	75010663	
42	C10	FOOT ASSY, REAR	75010810	
43	C11	COVER, IO	75010673	
44	C12	COVER, IR, REAR	75010678	
45	F1	FAN, AFB0512VHD-7F49	75010676	
46	F2	FAN, AUB0512HHB-7G27	75010675	
47	F3	FAN, BUB04512MD	75010624	
48	M1	SPEAKER	75010625	
49	M2	MYLAR, BALLAST	75010649	
50	M3	SPONGE FAN5015	75010651	


No	Location	Description	Part No	
			P9	PX10
51	M5	DOME, METAL	75010647	
52	M6	HOLDER, FAN5015	75010646	
53	M7	GASKET, SHIELDING FOAM	75010650	
54	M8	MYLAR, IO DECORATION	75010644	
55	M9	SWITCH, THERMAL	75010633	
56	M10	SWITCH, LAMP COVER	75010674	
57	M11	SHEET, TOP	75010648	
58	M12	FOOT, RUBBER	75010643	
59	O1	OPTICS BLOCK	75010672	
60	O3	COLOR WHEEL ASSY	75010662	
61	O4	DMD	75010638	
62	O5	RING, ZOOM	75010640	
63	RC	REMOCON HAND UNIT	75010637	
64	S2	SCREW, M2.5*6*A1.9 NI	75010612	
65	S5	SCREW, M3*6*A2 NI	75010620	
66	S6	SCREW, M4*6*A2.6 NI	75010623	
67	S7	SCREW, M2.5*4*E0.8 NI	75010617	
68	S8	SCREW, 2.6*5*A1.6 NI	75010613	
69	S9	SCREW, M2.5*8*A1.9 NI	75010618	
70	W1	WIRE, CON-CON 2PIN BST(BST-LAMP)	75010632	
71	W2	WIRE, CON-CON 4PIN IR	75010631	
72	W3	WIRE, CON-CON 4PIN MB(CW)	75010635	
73	W4	WIRE ASSY, CON-SW (SAFETY SWITCH)	75010809	
74	W5	WIRE, CON-CON 5PIN BST	75010636	
75	W6	CABLE, FFC, 0.5P, 28PIN	75010630	
76	W7	WIRE, CON-CON12PIN-10PIN+2PIN P	75010634	

Appendix A: Main board IC function diagram

1. Front side



2. Rear side



TOSHIBA CORPORATION

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN